



# UG87 LoRaWAN Gateway

## Quick Start Guide



## Welcome

Thank you for choosing Ursalink UG87 LoRaWAN Gateway.

This guide teaches you how to install the UG87 and how to log in the web GUI to configure the device. Once you complete the installation, refer to the Ursalink UG87 User Guide for instructions on how to perform configurations on the device.

## Related Documents


This Quick Start Guide only explains the installation of Ursalink UG87 LoRaWAN Gateway. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
Ursalink UG87 Datasheet	Datasheet for the Ursalink UG87 LoRaWAN Gateway.
Ursalink UG87 User Guide	Users can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Ursalink website: <http://www.ursalink.com>.

## Declaration of Conformity

UG87 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact  
Ursalink technical support:  
Email: [support@ursalink.com](mailto:support@ursalink.com)  
Tel: 86-592-5023060  
Fax: 86-592-5023065

# 1. Packing List

Before you begin to install the UG87 LoRaWAN Gateway, please check the package contents to verify that you have received the items below.

## 1.1 Package Contents



1 × UG87



1 × Cellular Antenna




1 × LoRa Antenna  
(2 × LoRa Antennas for  
16-channel model)




1 × GPS Antenna



1 × WiFi Antenna  
(WiFi Version Only)



1 × Wall Mounting Kit



2 × Pole Mounting Kit



Screws



1 × Warranty Card




1 × Ethernet Cable(Optional)




1 × Power cable  
(AC/ DC Version Only)


### Optional Installation Accessories




+



1 × Pole Mount A + 2 × U-Bolt



+



1 × Pole Mount B + 2 × U-Bolt



Screws




**If any of the above items is missing or damaged, please contact your Ursalink sales representative.**

## 2. Hardware Introduction


### 2.1 Overview

#### A. Front Panel





- ① LoRa2 Antenna (only for 16-channel model)
- ② GPS Antenna
- ③ LTE Antenna
- ④ LoRa1 Antenna
- ⑤ Vent Plug

#### B. Rear Panel




- ⑥ Power Connector
- ⑦ Ethernet Port (PoE)
- ⑧ LED&SIM Area
- ⑨ WLAN Antenna
- LED&SIM Area
- ⑩ PWR: Power Indicator
- ⑪ SYS: System Indicator
- ⑫ SIM Card Slot
- ⑬ L2: Cellular Indicator
- ⑭ RST: Reset Button
- ⑮ L1: LoRa Indicator

#### C. Top & Bottom View



## 2.2 Dimensions (mm)



## 2.3 LED Indicators

LED	Indication	Status	Description
PWR	Power Status	On	The power is switched on
		Off	The power is switched off
SYS	System Status	Green Light	Static: Start-up
		Blinking slowly	the system is running properly
		Off	The system goes wrong
L1	LoRa Status	Green Light	Package Forwarder mode is running well.
		Off	Package Forwarder mode is running off.
L2	SIM Card Status	Off	SIM1 or SIM2 is registering or fails to register (or there are no SIM cards inserted)
		Green Light	Static: SIM1 or SIM2 has been registered and dialed up successfully

## 2.4 Reset Button

Function	Description	
	SYS LED	Action
Reset	Blinking	Press and hold the reset button for more than 5 seconds.
	Static Green → Rapidly Blinking	Release the button and wait.
	Off → Blinking	The gateway resets to factory default.

## 2.5 Ethernet Port Indicator

Indicator	Status	Description
Link Indicator (Orange)	On	Connected
	Blinking	Transmitting data
	Off	Disconnected
Rate Indicator (Green)	On	1000 Mbps mode
	Off	100 Mbps mode

### 3. Hardware Installation


#### Environmental Requirements

- Power Input: PoE (IEEE 802.3af standard) (Option: 100-240 VAC/9-48VDC)
- Power Consumption: Typical 4.9 W, Max 6.5 W (8 channels)  
                                   Typical 6 W, Max 8.2 W (16 channels)
- Ingress Protection: IP67
- Operating Temperature: -40°C to 70°C (-40°F -158°F)
- Relative Humidity: 0% to 95% (non-condensing) at 25°C/77°F

#### 3.1 SIM Card Installation

Remove the cover of the SIM card slot with a wrench and insert the sim card.


**Note:** Check the triangle icon of the sim card slot.



#### 3.2 Antenna Installation

##### 3.2.1 Remove the protective caps


Remove the protective caps from the antenna connectors. Take cellular connector as an example.



### 3.2.2 Connect the antenna

Connect the antenna to the corresponding antenna connector by holding on the metal part of the antenna and rotating it clockwise.

Note: Each antenna is labeled as cellular, GPS, WLAN or LoRa.




## 3.3 Power Connection

### 3.3.1 PoE Power Supply


#### 3.3.1.1 Connect UG87 to PoE Switch

Connect UG87 Ethernet port to a PoE switch via Ethernet cable. PoE switch must meet IEEE 802.3 af standard.



#### 3.3.1.2 Connect UG87 to PoE Injector


Connect UG87 Ethernet port to a PoE injector via Ethernet cable. PoE injector must meet IEEE 802.3 af standard.



### 3.3.2 AC/DC Power Supply (Optional)


#### 3.3.2.1 Remove the protective caps

Locate the power port marked POWER on the left side of the enclosure and remove the protective cap to find the connection pins.




#### 3.3.2.2 Connect the power cable

Connect a power supply cable to the power port, and rotate it clockwise.




Type	PIN	Color	Description
VAC	1	Brown	L (VIN+)
	2	Black	GND
	3	Blue	N (VIN-)





Type	PIN	Color	Description
VDC	1	Brown	V+
	2	Black	GND




### 3.4 Mount Gateway

The gateway can be mounted to a wall or a pole.

#### 3.4.1 Wall Mounting

Make sure you have mounting bracket, bracket mounting screws, wall plugs, wall mounting screws and other required tools.

1. Before you start, make sure that your SIM card has been inserted, your antennas have been attached and that all cables have been disconnected from your enclosure.
2. Mount the enclosure to the mounting bracket with the bracket mounting screws.




3. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

**Note:** The connecting lines of adjacent points are at right angles.

4. Drill the four holes with a depth of 32 mm by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.
5. Insert four wall plugs into the holes respectively.
6. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.

**Note:** Place the power port on the button when installing.




7.Reconnect the cables.


### 3.4.2 Pole Mounting ( Hose clamp)

Make sure you have mounting bracket, bracket mounting screws, hose clamp and other required tools.

1. Before you start, make sure that your SIM card has been inserted, your antennas have been attached and that all cables have been disconnected from your enclosure.
2. Mount the enclosure to the mounting bracket with the bracket mounting screws.




3.Loosen the hose clamp by turning the locking mechanism counter-clockwise.



4.Straighten out the hose clamp and slide it through the rectangular holes in the mounting bracket, wrap the hose clamp around the pole.

5. Use a screwdriver to tighten the locking mechanism by turning it clockwise.




6. Reconnect the cables.

### 3.4.3 Pole Mounting (U-bolt)


**Note:** Pole mounting (U-bolt) is optional.

Make sure you have mounting bracket, bracket mounting screws, hose clamp and other required tools.

1. Before you start, make sure your SIM card has been inserted, your antennas have been attached and that all cables have been disconnected from your enclosure.
2. Mount the enclosure to the mounting bracket with the bracket mounting screws.



3. Wrap the U-bolt around the pole and mount the bracket with the mounting screws.




4.Reconnect the cables.


## Getting Started

### 4. PC Configuration for UG87 Web GUI


PC can obtain an IP address, or you can configure a static IP address manually. The following steps are based on Windows 10 operating system for your reference.




① Click “Search Box” to search “Control Panel” on the Windows 10 taskbar.






② Click “Control Panel” to open it, and then click “View network status and tasks”.



③ Click “Ethernet” (May have different names).



④ Click “Properties”.



⑤ Double Click “Internet Protocol Version 4 (TCP/IPv4)” to configure IP address and DNS server.

⑥ Method 1: click “Obtain an IP address automatically”;

Method 2: click “Use the following IP address” to assign a static IP manually within the same subnet of the gateway.

(Note: Remember to click “OK” to finish configuration.)

## 5. Access to UG87 Web GUI for Cellular Connection

This chapter explains how to log in UG87 Web GUI, and connect the gateway to cellular network. Ursalink UG87 provides web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below:

IP Address: **192.168.1.1**


Username: **admin**


Password: **password**

### 5.1 Log in the Gateway


 **Make sure your PC is connected to the same network as shown in [Section 4](#).**

- A. Start a Web browser on your PC (Chrome and IE are recommended), type in the IP address, and press Enter on your keyboard.
- B. Enter the username and password, click “Login”.




 **If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.**

C. When you log in with the default username and password, you will be asked to modify the password. It’s suggested that you change the password for the sake of security. Click “Cancel” button if you want to modify it later.




D. After you log in the Web GUI, you can view system information and perform configuration on the gateway.




## 5.2 Configure the Cellular Connection

Take inserting SIM card into SIM1 slot as an example; please refer to the following detailed operations.

- A. Click “Network” → “Interface” → “Cellular” → “Cellular Setting” to configure the cellular info.
- B. Enable SIM1.
- C. Choose relevant network type. “Auto”, “4G First”, “4G Only”, “3G First”, “3G Only”, “2G First” and “2G Only” are optional.
- D. Click “Save” and “Apply” for configuration to take effect.








If you select “Auto”, the gateway will obtain ISP information from SIM card to set APN, Username, and Password automatically. This option will take effect when the SIM card is issued from a well-known ISP. If you select “4G First” or “4G Only”, you can click “Save” to complete the configuration directly. If you select “3G First”, “3G Only”, “2G First” or “2G Only”, you should manually configure APN, Username, Password, and Access Number.

UG87 have two cellular interfaces, named SIM1 & SIM2. Only one cellular interface is active at one time. If both cellular interfaces are enabled, SIM1 interface takes precedence by default.

### 5.3 Check the Cellular Connection Status

#### 5.3.1 Check the Cellular Connection Status by Web GUI of Gateway

Click “Status” → “Cellular” to view the status of the cellular connection. If it shows “Connected”, it means SIM1 has dialed up successfully.



Status	Overview	LoRa	Cellular	Network	VPN
LoRaWAN	<b>Modem</b>				
	Status		Ready		
Network	Model		EC25		
System	Current SIM		SIM1		
Industrial	Signal Level		31asu (-51dBm)		
Maintenance	Register Status		Registered (Home network)		
APP	IMEI		861107032321490		
	IMSI		460110269496240		
	ICCID		89860317245923922835		
	ISP		CHN-CT		
	Network Type		LTE		
	PLMN ID		46011		
	LAC		5f02		
	Cell ID		5fb0d34		
	<b>Network</b>				
	Status		Connected		
	IP Address		172.21.143.187		
	Netmask		255.255.255.248		
	Gateway		172.21.143.188		
	DNS		218.85.152.99		
	Connection Duration		0 days, 00:01:39		

### 5.3.2 Check the Cellular Connection Status by Hardware

On the other hand, you can check the status of SIM1 indicator. If it keeps on green light statically, it means SIM1 has dialed up successfully.

### 5.4 Check if Network Works Properly by Browser on PC

Open your preferred browser on PC, then type any available web address into address bar and see if it is able to visit Internet via UG87.

## 6. Packet Forwarder Testing

### 6.1 Node Parameters

Channel Plan	AS923
Frequency	923.4MHZ, 923.2MHZ
Join Type	OTAA
Device EUI	60C5A8FFFE0003F9
Application EUI	70B3D57ED0007AC2
App Key	328F2A3F5BA8D0B236459CF06D0512B5

### 6.2 Configure The Things Network

#### A. Gateway Configuration

Gateway EUI	24E124FFFEF0132E
Frequency Plan	Asia 920-923MHZ
Server ID	Switch-router (ttn.opennetworkinfrastructure.org)

**GATEWAY SETTINGS**

- General
- Owner
- Location
- Privacy
- Information
- Collaborators

**GENERAL**

**Description**  
A human-readable description of the gateway  
USRALINK

**Frequency Plan**  
The frequency plan this gateway will use  
Asia 920-923MHz

**Router**  
The id of the router your gateway will connect to.  
switch-router


**Automatically update gateway**  
If enabled the gateway will periodically check if updates are available and perform them.  
Enabling auto updates may cause your gateway to have unexpected downtime when updating

**Beta Updates**  
Turn this on to receive firmware from the beta release channel.

#### B. Applications Configuration


**APPLICATIONS** + add application

Application ID	Name	EUI
123454321	USRALINK	70 B3 D5 7E D0 00 7A C2



### 6.3 Packet Forwarder Configuration

A. Click “LoRaWAN” → “Packet Forwarder” → “General” to configure the general setting.



B. Click “Radios” to configure the center frequency and channels.

General **Radios** Advanced Custom Traffic

**Radio Channel Setting**

Supported Frequency: AS923

Name	Center Frequency/MHz
Radio 0	923.6
Radio 1	922.6

**Multi Channels Setting**

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	923.2
<input checked="" type="checkbox"/>	1	Radio 0	923.4
<input checked="" type="checkbox"/>	2	Radio 0	923.6
<input checked="" type="checkbox"/>	3	Radio 1	922.2
<input checked="" type="checkbox"/>	4	Radio 1	922.4
<input checked="" type="checkbox"/>	5	Radio 1	922.6
<input checked="" type="checkbox"/>	6	Radio 1	922.8
<input checked="" type="checkbox"/>	7	Radio 1	923.0

C. Click "Traffic" to view the data communication of UG87

General Radios Advanced Custom **Traffic**

**Traffic Setting**

Stop Clear

Rfch	Direction	Time	Ticks	Frequency	Datarate	Coderate	RSSI	SNR
1	up	-	2422567628	922.6	SF7BW125	4/7	-86	-11.5
1	up	-	2027425380	923.0	SF7BW125	4/6	-87	-10.8
1	up	-	1906152459	922.2	SF7BW125	OFF	-89	-11.8
0	up	-	1896642603	923.6	SF7BW125	4/6	-89	-12.0
0	up	-	1833066556	923.8	SF7BW250	4/5	-86	-12.0
0	up	-	1793222443	923.4	SF7BW125	4/8	-85	-11.2
0	up	-	1768923067	923.2	SF7BW125	4/5	-89	-11.8
1	up	-	1736475188	922.8	SF8BW125	4/8	-86	-14.0
1	up	-	1504937860	923.0	SF7BW125	4/5	-87	-11.5

## 6.4 Check Data Transmission on The Things Network

A. Click "Gateways", you can check the Gateways status.

Gateways

**GATEWAYS** [register gateway](#)

---

eui-24e124ffffef0132e USRALINK ● connected AS\_920\_923

B. Click “Applications” and select the Applications, then go to “Data”, you can find the data from the Node.

Applications

**APPLICATIONS** [add application](#)

---

123454321 USRALINK *switch-handler* 70 B3 D5 7E D0 00 7A C2

Applications > 123454321 > Data

Overview Devices Payload Formats Integrations **Data** Settings

**APPLICATION DATA**  pause clear

Filters uplink downlink activation ack error

time	counter	port		dev id:	
14:23:03		0		ursalink	
14:23:01	3	8	retry confirmed	ursalink	payload: 53 01 00 00 01 00 00 64
14:22:57		0		ursalink	
14:22:55	3	8	retry confirmed	ursalink	payload: 53 01 00 00 01 00 00 64
14:22:52		0		ursalink	
14:22:50	3	8	confirmed	ursalink	payload: 53 01 00 00 01 00 00 64
14:22:43		0		ursalink	

## 7. Network Server Testing

**Note** that only gateway with activated built-in Network Server supports this function.


### 7.1 Node Parameters

Channel Plan	AS923
Frequency	923.4MHZ, 923.2MHZ
Join Type	OTAA
Device EUI	60C5A8FFFE0003F9
Application EUI	70B3D57ED0007AC2
App Key	1A98A25536993A882154B81551F18A76


### 7.2 Network Server Configuration

A. Click “LoRaWAN” → “Network Server” → “General” to configure the general setting.

**Note** that the channel plan of the nodes and network server need to be the same.



B. Add a new Application.



General **Applications** Profiles Device Packets

**Applications**

Name

Description

Payload Codec

Add data transmission information (HTTP/HTTPS/MQTT).

**Data Transmission**

Type	Operation

General **Applications** Profiles Device Packets

**Applications**

Name

Description

Payload Codec

**Data Transmission**

Type

- MQTT
- HTTP
- MQTT**
- HTTPS

**General**

Broker Address

Broker Port




General **Applications** Profiles Device Packets

**Applications**

ID	Name	Description	Payload Codec	Operation
8	Smoke-Sensor-APP	Smoke Sensor	None	



C. Add Profiles for the device



D. Add device

General Applications Profiles **Device** Packets

**Device**

**General**

Device Name:

Description:

Device EUI:

Device-Profile:

Application:

Frame-counter Validation:

**Activate Device(OTAA)**

Application Key:

Device Address:

Network Session Key:

Application Session Key:

Uplink Frame-counter:

Downlink Frame-counter:

General Applications Profiles **Device** Packets

**Device**

Device Name	Device EUI	Device-Profile	Application	Last Seen	Actived	Operation
Somke-Sensor	60c5a8fffe0003f9	Smoke-Sensor	Smoke-Sensor-APP	-	---	<input type="button" value="edit"/> <input type="button" value="delete"/>
						<input type="button" value="add"/>

### 7.3 Package Forwarder Configuration

Click “LoRaWAN” → “Packet Forwarder” → “Radios” to configure the center frequency and channels

**Note** that node frequency needs to be included in the channels frequency.

General **Radios** Advanced Custom Traffic

**Radio Channel Setting**

Supported Frequency: AS923

Name	Center Frequency/MHz
Radio 0	923.6
Radio 1	922.6

**Multi Channels Setting**

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	923.2
<input checked="" type="checkbox"/>	1	Radio 0	923.4
<input checked="" type="checkbox"/>	2	Radio 0	923.6
<input checked="" type="checkbox"/>	3	Radio 1	922.2
<input checked="" type="checkbox"/>	4	Radio 1	922.4
<input checked="" type="checkbox"/>	5	Radio 1	922.6
<input checked="" type="checkbox"/>	6	Radio 1	922.8
<input checked="" type="checkbox"/>	7	Radio 1	923.0

## 7.4 Check the Packets

Click “LoRaWAN” → “Network Server” → “Packets” to check the packets from the node on network server.

For your device security, please change the default password

General Applications Profiles Device **Packets**

**Send Data To Device**

Device EUI: 0000000000000000 Type: ASCII Payload: Fport: Confirmed:

**Send**

**Network Server**

**Clear** Search

Device EUI	Frequency	Datarate	SNR	RSSI	Size	Fcnt	Type	Time	Details
1114611693255998	868500000	SF10BW125	6.2	-112	11	62	UpUnc	2019-09-16T21:31:17+08:00	<a href="#">!</a>
1114611693255998	868300000	SF10BW125	8.8	-108	11	61	UpUnc	2019-09-16T21:30:17+08:00	<a href="#">!</a>
1114611693255998	868300000	SF10BW125	9.2	-103	11	60	UpUnc	2019-09-16T21:29:17+08:00	<a href="#">!</a>
1114611693255998	868100000	SF10BW125	8.8	-113	11	59	UpUnc	2019-09-16T21:28:17+08:00	<a href="#">!</a>
1114611693255998	868100000	SF10BW125	12.2	-100	11	58	UpUnc	2019-09-16T21:27:17+08:00	<a href="#">!</a>
1114611693255998	868300000	SF10BW125	9.0	-104	11	57	UpUnc	2019-09-16T21:26:17+08:00	<a href="#">!</a>
1114611693255998	868100000	SF10BW125	10.8	-106	11	56	UpUnc	2019-09-16T21:25:17+08:00	<a href="#">!</a>
1114611693255998	868500000	SF10BW125	8.2	-109	11	55	UpUnc	2019-09-16T21:24:17+08:00	<a href="#">!</a>

[END]